

Please note installation is a guide only, ABI recommends to consult with your builder to ensure fixing strength will be sufficient. For applications with unusually heavy benchtops and/or sinks are used brackets may be required



## installation guide Addison

Step 1: Locate studs or point of fixing (pre knogging is recommended)

Step 2: Using a level mark a level line to dictate the "top of bench line" (generally 800-850mm from finished floor line for top mounted free standing sinks. 900mm for recessed sinks)

Step 3: Mark holes using method shown in diagram on the right, keeping holes approx. 50mm from each edge/corner internal of the modular units

Step 4: Line top of sink up with the level line marked on wall lining, fix both ends and work your way to the middle. ABI recommends use of minimum 25mm diameter washers with batten screws. Install aluminium angle to under side of unit (Minimum 30mm x 30mm x 3mm angle)

Step 5: Install stone bench top using an epoxy or silicone adhesive. Ensure all screws are in place prior to placing weight of bench on cabinet. After installation silicone all edges that meet wall surface to avoid water entry during use.

